

At Your Service Heating and Cooling

Will perform the following procedures on all

ELECTRIC HEAT only (no air conditioning) M.A.-PTUS

1. Cycle the complete system (heating as well as fan operation).
2. Replace up to one standard 1" throwaway filter, or clean one permanent filter per system.
3. Remove and clean the indoor blower assembly, which includes the blower wheel on the indoor unit.
4. Remove and clean the indoor blower motor on the indoor unit.
5. Remove any trash or debris from indoor unit.
6. Lubricate all moving parts on indoor unit.
7. Test and record all voltages on indoor blower motor.
8. Test and record all amperages on indoor blower motor.
9. Test and examine all controls on indoor unit.
10. Tighten or adjust all belts and pulleys within indoor unit.
11. Examine and tighten all electrical connections on the indoor unit.
12. Clean and apply protective coating to indoor cabinet.
13. Test and record voltage on electric heat strips.
14. Test and record amperages on electric heat strips.
15. Test and record indoor air temperature.
16. Test and record indoor air temperature rise in heating mode.