

At Your Service Heating and Cooling

Will perform the following procedures on all

GAS HEAT only (no air conditioning) M.A.-PTUS

1. Cycle the complete system (heating as well as fan operation).
2. Replace up to one standard 1” throwaway filter, or clean one permanent filter per system. – Supplied by customer.
3. Remove and clean the indoor blower assembly, which includes the blower wheel on the indoor unit.
4. Remove and clean the indoor blower motor on the indoor unit.
5. Remove any trash or debris from indoor unit.
6. Lubricate all moving parts on indoor units.
7. Test and record all voltages on indoor blower motor.
8. Test and record all amperages on indoor blower motor.
9. Test and examine all controls on indoor unit.
10. Tighten or adjust all belts and pulleys within indoor unit.
11. Examine and tighten all electrical connections on the indoor unit.
12. Clean and apply protective coating to indoor cabinet.
13. Clean and adjust burner assembly.
14. Test and clean ignition assembly.
15. Clean heat exchanger and examine for possible cracks.
16. Test and record gas pressures at indoor furnace.
17. Leak test for gas leaks at furnace gas piping connections.
18. Monitor flue draft on gas furnace.
19. Test and record indoor air temperature.
20. Test and record indoor temperature rise in heating mode.